## PARTS LIST

for

# **KitchenAid**<sub>®</sub>

# PROLINE CHEF'S BLENDER

### 3-SPEED HOUSEHOLD/PLASTIC JAR

#### **MODELS:**

KPCB348PPM0 (Pearl Metallic) 4KPCB348PPM0 (Pearl Metallic)



FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS





KITCHENAID


ST. JOSEPH MICHIGAN 49085

### **JAR ASSEMBLY PARTS**

For Models: KPCB348P\_\_0, 4KPCB348P\_\_0








Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8204582	Use & Care Guide
	8204582	U.S.
	8212224	Canada
		Repair Parts List
2	8212228	Cap, Ingredient
3	8211478	Lid Assembly
4	8212227	Jar, Plastic
		(Incl Blade Asm)
5	8212280	Blade Assembly


# MOTOR AND HOUSING PARTS For Models: KPCB348P\_\_0, 4KPCB348P\_\_0



Illus. No.	Part No. D	ESCRIPTION
1 2 3 6 7 8 9 10 11 12 13 16	4176869 4176870 4176873 4176874	Screw, 10 x 16 Base Screw, 10 x 16

#### **ESCUTCHEON AND CONTROL PARTS**

For Models: KPCB348P\_\_0, 4KPCB348P\_\_0



4176858 Bezel, Switch

4176881 Screw, Plastic

4176877 Screw 10 x 16

4176872 EMC-PC Board

4176871 EMC Mount

4176882 Main PCB 4176897 Nut, Plastic

4176883 Mount, Main PCB

4176875 Screw, PCB Mount

11 12

13

14

15

16

17

18 19